















1. Raumsteuerungen / Room control devices

<p>Display-Einsatz Display insert 29 0700 80...</p> 	<p>Ruf-/Anwesenheits-Einsatz Call/presence insert 29 0701 00...</p> 
<p>Display-Einsatz Display insert 29 0700 80... Intercom-Einsatz Intercom insert 29 0701 30...</p> 	<p>Ruf-/Anwesenheits-Einsatz Call/presence insert 29 0701 00... Intercom-Einsatz Intercom insert 29 0701 30...</p> 



2. Taster / Switches

<p>Anwesenheits-Einsatz Presence insert 29 0706 00...</p> 	<p>Ruftaster-Einsatz mit Steckvorrichtung Call switch insert with connector 29 0704 00...</p> 	<p>Ruftaster-Einsatz Call switch insert 29 0708 00...</p> 
<p>Abstelltaster-Einsatz Cancel switch insert 29 0709 00...</p> 	<p>Zugtaster-Einsatz Pull cord switch insert 29 0707 20...</p> 	<p>Pneumatiktaster-Einsatz Pneumatic switch insert 29 0707 50...</p> 
<p>RAN-Schnittstelle RAN interface 19 0840 00</p> 		





3. Zimmerleuchten, Flurdisplays / Room lamps, Corridor displays

<p>Zimmerleuchte Universal, 3-teilig Room lamp universal, 3 sections 77 0180 10, 77 0185 10</p> 	<p>Zimmerleuchte Universal, 3-teilig, mit Türschild Room lamp universal, 3 sections, with doorplate 77 0181 10</p> 	<p>Flurdisplay, 12-stellig Corridor display, 12 digits 29 0783 12, 29 0784 12 Flurdisplay, 16-stellig Corridor display, 16 digits 19 0783 16, 19 0784 16</p> 
---	--	--




4. Steckbare Rufgeräte / Plug-in call devices

<p>Birntaster mit Ruf- und Lichttaste Pear push switch incl. call & light switch 29 0790 02</p> 	<p>Birntaster mit Ruftaste Pear push switch incl. call switch 29 0790 00</p> 
---	--


5. Systemsteuerung / System control

<p>Management Interface 29 0700 00</p> 	<p>Systemschnittstelle LAN System interface LAN 19 0700 05</p> 
<p>Gruppencontroller Group controller 29 0700 10</p> 	<p>Brandmelde Interface Fire alarm interface 19 0800 84</p> 

6. Drahtlose Rufgeräte / Wireless call devices

<p>Funkempfänger-T Radio receiver-T Z 00 8202 36</p> 	<p>Funkempfänger-T UP Radio receiver-T UP Z 00 8202 35</p> 
<p>MyAmie P68007/02</p> 	

7. Netzgeräte / Power supply units

<p>Netzgerät 6A USV Power supply unit 6A UPS 77 3400 60</p>	<p>Netzgerät 6A Power supply unit 6A 77 3401 60</p>	
---	---	---